

part numbers

Bilge Pump Panel 3-way 12/24V 01-66-027 Bilge Pump Panel 3-way 12/24V bulk 01-66-028

Bilge Pump Panel 12V/24V

- 3-position control switch panel for complete control over your bilge pumps.
- · Switch positions manual ON, OFF and Automatic.
- The automatic feature operates in combination with automatic bilge level switches (for example: Albin Pump Marine Digital Bilge Switch part no. 01-66-036 or Bilge Float Switch part no. 01-66-025) or automatic bilge pumps (Albin Pump Marine Submersible Automatic Bilge Pumps 500 GPH – 1100 GPH part nos. 01-04-015 – 019).
- Integrated operating light and fuse holder. Fuses are not included. Select
 the fuse according to the recommended fuse size of the connected pump;
 refer to the pump manual

Electrical Installation:

See the wiring diagrams in figures 1, 2 and 3. **Important**: all electrical wiring must be clamped with the connections well above the bilge water level.

Do not remove the insulation more than necessary. All wiring connections should be sealed with a marine sealant to avoid oxidation




Figure 1 Wiring for 3-way Bilge Pump Panel with Digital Bilge Switch





Figure 2 Wiring for 3-way Bilge Pump Panel with Bilge Float Switch






Figure 3 Wiring for 3-way Bilge Pump Panel with Automatic Bilge Pump



Caution! Keep all wired connections above the highest water level. Wires must be joined with butt connectors and a marine grade sealant to prevent wire corrosion



Caution! Always install proper fuse size to prevent damage to product should a short occur. Failure to install proper fuse could increase risk of pump malfunction, potentially resulting in personal injury and/or fire hazard.




Figure 4 Template for mounting the Bilge Pump Panel (scale 1:1)

Cut out a rectangular hole 70 mm x 45 mm (W x H) in the mounting surface to accommodate the electronics. Drill 4 appropriate sized holes for your preferred fasteners to secure the switch panel to its mounting surface.









At the product's end of life, please dispose of the product according to applicable law. Where applicable, please disassemble the product and recycle the parts according to material.



Albin Group AB Kämpevägen 17

Kampevagen 17 55302 Jönköping, Sweden info@albin.group www.albin.group