

Active Carbon Filter

Part nr. 03-66-011

Prevents outside odor coming from tank by connecting it at the highest point along the breather hose.

With 16, 19, 25 mm (%", ¾", 1") adjustable ports


Waste water holding tank ventilation

To facilitate the dispersal of gases built up in the tank and the ease of emptying, the tank must be ventilated. The holding tank vent carbon filter will absorb heavier-than-air gases associated with organic waste and eliminate a source of malodor from the vent at the exterior of the boat.

- Holding tank vent lines must be free of low points which can trap liquid and prevent the free flow of gases from or air into the holding tanks.
- Use only reinforced hose for vent lines. Otherwise, over time, the hose will tend to kink and effectively block the vent.

When installing vent filters that are not mounted directly on a holding tank unit:

- Avoid areas near excessive heat sources such as engine manifolds or lights.
- Do not install the filter below top of holding tank.
- The filter can be mounted in any position. Installations near the through-hull vent reduce the chance of filter damage from overfilling of the holding tank.





Waste handling & material recycling

At the product's end of life, please dispose of the product according to applicable law. Where applicable, please disassemble the product and recycle the parts according to material.



